













PETITE CUISINIÈRE À CLIPSER EASY TO CLIP WOODEN KITCHEN

KLEINE HOLZKÜCHE / HOUTEN KEUKENTJE
PEQUEÑA COCINA DE MADERA / PICCOLA CUCINA IN LEGNO
木制小炊具 / المطبخ الخشبي الصغير

		
Ax1	Bx1	Cx1
		
Dx1	Ex1	Fx1
		
Gx1	Hx1	Ix1
		
Jx1	Kx1	H1x1


À monter par un adulte.
For assembly by an adult.
Muss von einem Erwachsenen zusammengebaut werden.
Door een volwassene te worden gemonteerd.
Debe montarlo un adulto.
Da assemblare a cura di un adulto.
应由成年人组装
التجميع من قبل شخص بالغ

Informations à conserver.
Information to be kept.
Informationen aufbewahren.
Gegevens moeten worden bewaard.
Conservar esta información.
Informazioni da conservare.
应保留的信息。
معلومات يجب الاحتفاظ بها.




336730
Oxybul éveil et jeux
162 boulevard de Fourmies
59100 Roubaix - FRANCE


1




2




3




4




5



6



7



8

